Written by emmeci

Friday, 27 April 2007 23:43 - Last Updated Thursday, 10 March 2011 09:53



The PRG1-Com software is used to set all the operating parameters required by the MC-PRG1 program

PRG1-Com is used to set work sizes (length of the adhesive sections and pauses, name of size) with po

PRG1-Com also has a complete diagnosis procedure used to check the efficiency of the spray starting sensors (trigger) of the outputs and of the encoder.

If the system is used in encoder mode, PRG1-Com is used to set the operational parameters (data related to the encoder, minimum and maximum working speed, gun compensations) either manually or via automatic teach-in.

PRG1-COM - demo of the software for managing the MC-PRG1 programmer

Written by emmeci Friday, 27 April 2007 23:43 - Last Updated Thursday, 10 March 2011 09:53

Minimum system requirements:

- Operating system: Windowsâ"¢ 95, 98, ME,NT4, 2000, XP
- Computer: 100% Windowsâ"¢ compatible with serial port RS232
- CPU: 200MHz or superior

Windowsâ"¢ is a registered trade mark owned by Microsoft Corporation



Download (Ita - 2,80 MB)

Ã,Â

If you need English version of the software please send an e-mail to info@emmeci-elettronica.
com
This e-mail address

is being protected from spambots. You need JavaScript enabled to view it

PRG1-COM - demo of the software for managing the MC-PRG1 programmer

Written by emmeci Friday, 27 April 2007 23:43 - Last Updated Thursday, 10 March 2011 09:53
Related arguments:
- Programmer for sections of adhesive in modular version MC-PRG1